Compatibility









Furone

Your universal travel adapter can be used with a wide variety of electronics, such as tablets, phones, laptop computers, gaming devices, electric razors, and GPS devices, up to a max of 1,840W at 230V and 880W at 110V.

WARNING: This adapter does not convert voltage! Make sure your electronics match the voltage of the outlet you want to use (110 or 220) before you plug them in! Mismatched voltage may cause damage to vour electronics.

Using the adapter



For the US, Canada, Japan, and Taiwan (2-corner flat) Slide the USA/AUS plug out completely. Make sure the blades are parallel.







For China (Mainland), Australia, New Zealand (octagon pins) Slide the USA/AUS plug out completely. Turn the blades in at the top as shown here.





For the UK, Hong Kong, Malaysia, Singapore (UK 3 pins) Slide the UK plug out completely.





For Germany, France, the Netherlands, Belgium (EU universal round pin) Slide the EU plug out completely.



To retract the pins: Push the square button on the side of the adapter and slide the pins back.


Replacing the fuse

Your adapter has an 8A overload fuse that automatically cuts off power when overloaded, protecting your devices from a potentially damaging surge.



To replace the fuse: Remove the fuse cover (1). Remove the old fuse (2). Replace with the spare fuse included (3).

Tour of the adapter





universal travel adapter

quick start guide